

Shade Guide	ROE Dental Laboratory Shade Conversion to Vivodent PE Shades																			
SR-Vivodent PE	O1	1A	1C	2A	2B	1D	1E	2C	3E	2E	3A	5B	3C	4C	4A	4B	6B	6C	6D	4D
Chromascop	110 120	130 140	220 310	210		230	240		340		330	320	530		410 440		420	430	520 510	540
Bioform	51 59 91	66 52 54 63 92	55 56	67 65 53 94	77 81	83		84 82				85			69	96	93	95		
SLM	T1 T2 T9	T3 T4 T10	T16 T24	T11 T12 T15 T5 T3 T14 T22 T23	T19 T17		T20							T21		T6 T8 T18		T7		
Bioblend	100 102	104	108 109	110 106	116				118			114			113	113				
Portrait	P21 P32 P59	P3 P2 P12 P66 P62	P13 P65 P67 P77	P65 P14 P69	P35	P33								P24	P22	P4	P34		P23	
Vita Lumin	A1 B1 B2 C1	A2 A3		B3	A3.5				A4			B4		C4	D4		D3	C2 C3		